

**Power bank INTENSO Powerbank XS 10000Mah white  
 7313532**



Codice	CK333631
EAN	4034303028405
Marca	INTENSO
Part number	7313532
Storage unit	
Unità di vendita	Cadauno
Confezione	1
Imballaggio	1
Peso (kg)	0.335
Volume (cm <sup>3</sup> )	637.5

**POWERBANK XS 10000**

Battery: 10000 mAh,

Colours: Black & White (all capacities),

Petrol, Rose & Blue (5000 / 10000 mAh)

Battery type: Li-polymer battery

Connections: Output: USB-A + USB-C

XS5000: 5V - 2.1A

XS10000 & XS20000: 5V - 3.1A

Input: microUSB + USB-C

XS5000: 5V - 2.1A

XS10000 & XS20000:

USB-C: 5V - 2.4A

microUSB: 5V - 2.1A

Display: Blue LED display

Characteristics: Overvoltage protection, discharge

protection, overcharge protection,


short circuit fuse

Accessories: USB-A to USB-C charging cable

Dimensions & Weight: XS5000: 90 x 63 x 12,6 mm, 103 g

XS10000: 91 x 63 x 22 mm, 182 g

XS20000: 128 x 70 x 25,2 mm, 343 g



SPECIFICHE	
Marca	INTENSO

GENERALE	
Numero porte USB	2
Tipo connettore 1 input	USB-C
Colore primario	Bianco

CARATTERISTICHE TECNICHE	
Tipologia connettore output	1 x USB-A + 1 x USB-C
Input Voltaggio	5 V
Input Amperaggio	2,4 A
Output Voltaggio	5 V
Output Amperaggio	3,1 A
Output Voltaggio seconda porta USB	5 V
Tempo di ricarica	3 h
Contenuto della confezione	BATTERY BANK + CAVO RICARICA

PESO E DIMENSIONI	
Altezza	91 cm
Larghezza	22 cm
Lunghezza	63 cm
Peso	182 gr

BATTERIA	
Batteria	10000 mAh